

ANTIL[®] Soft SC

The natural choice for a multifunctional thickening agent for Rinse-Off

- Excellent thickening in various surfactant systems
- Foam boosting even in PEG-free systems
- Improves foam creaminess and skin feel
- Reduces moisture loss after surfactant treatments
- Highly efficient as solubilizer
- PEG-free, natural based, high active matter
- Complies with Ecocert standards
- Readily biodegradable
- Liquid – easy to process
- Economic advantage

Personal Care

INCI Name (CTFA Name)

Sorbitan Sesquicaprylate

Chemical and physical properties (not part of specifications)

Form	liquid
Appearance (25°C)	clear
Active matter	>99 %
Solubility in	
- Water	dispersable
- Ethyl Alcohol	soluble
- Surfactant formulas	clearly soluble*

* depending on the concentration and systems

Properties

ANTIL® Soft SC is a liquid cosmetic ingredient with the following properties:

- excellent thickener
- foam booster
- improved skin after-feel
- reduces moisture loss after surfactant treatments
- solubilizer for fragrances and emollients

ANTIL® Soft SC can be utilized at low levels to produce clear body washes or shampoos. ANTIL® Soft SC is cold processable, due to its relatively low viscosity and low pour point, thus it is very easy to process.

Thickening

Figure 1 shows an overview of the thickening efficacy in a typical surfactant system, e.g. 9% SLES / 3% CAPB / 0.7% NaCl. The graph indicates the concentration of thickener, which was needed to achieve a viscosity of 3500 mPas. ANTIL® Soft SC shows superior performance over more commonly used surfactant thickeners.




Figure 1: Thickening efficacy of different surfactant thickeners:

ANTIL® 171 = PEG-18 Glyceryl Oleate/Cocoate
 REWODERM® LI S 80 = PEG-200 Hydrogenated Glyceryl Palmate; PEG-7 Glyceryl Cocoate
 REWOMID® DC 212 S = Cocamide DEA

Figure 2 shows the outstanding thickening efficacy ANTIL® Soft SC in a PEG-free surfactant system based on 4.8 % Sodium Cocoamphoacetate / 4.9 % CAPB / 3.6 % Disodium Lauryl Sulfosuccinate / pH=5.5.

ANTIL® Soft SC can replace the PEG-free thickening agent. An 80 % decrease in the use level was obtained while achieving a viscosity of 3500 mPas.

Additionally, ANTIL® Soft SC can be used as a co-thickener. By adding a small amount of ANTIL® Soft SC to a standard PEG-free thickening agent, the amount of thickener could be reduced by 66 % in order to achieve the same viscosity.




Figure 2: Thickening effect in a PEG-free surfactant system. Viscosity (Brookfield) = 3500 mPas.

ANTIL® HS 60 = Cocamidopropyl Betaine; Glyceryl Laurate

Foam boosting in PEG-free formulation

Compared to standard surfactant systems, PEG-free surfactant systems display inferior foam quality and quantity. The addition of 0.5 % ANTIL® Soft SC to a PEG-free surfactant formula significantly improves all tested foam parameters: flash foam, foam volume and foam creaminess (figure 3).




Figure 3: foam results of a sensory hand wash test with a 10 person panel.

Surfactant base: 3.6% Disodium Lauryl Sulfosuccinate / 4.8% Sodium Cocoamphoacetate / 4.9% Cocamidopropyl Betaine / pH=5.5

Improvement of foam and skin feel

ANTIL® Soft SC enhances the foam creaminess and improves skin feel in rinse-off applications. The results of a sensory hand wash test (10 person panel) with surfactant formulations which include PEG-7 Glyceryl Cocoate (TEGOSOFT® GC) as the market standard are shown in *Figure 4*. For most properties, ANTIL® Soft SC outperforms the standard, even with lower concentration.




Figure 4: results of a sensory hand wash test with a 10 person panel.

Surfactant base: 9% SLES / 3% CAPB / 1% NaCl / pH=5.5

Skin Hydration

Surfactant treatments in general reduce the moisture content of the skin. *Figure 5* shows the result of corneometer measurements after 11 surfactant treatments within 5 days. The addition of ANTIL® Soft SC reduces moisture loss by 31% compared to standard (statistically significant).




Figure 5: results of Corneometer measurements after 11 surfactant treatments within 5 days on 30 test persons, conducted by an independent institute.

Surfactant base: 12% SLES / 2% additive/ pH=6

Solubilizing

ANTIL® Soft SC provides efficient solubilizing properties in surfactant formulas. It outperforms standard solubilizer such as Polysorbate-20 (TEGO® SML 20), PEG-40 Hydrogenated Castor Oil (TAGAT® CH 40) and PEG-7 Glyceryl Cocoate (TEGOSOFT® GC). *Figure 6* shows the amount of clearly solubilized Isopropyl Myristate (IPM) in a surfactant base plus 0.5% of the respective additive after 10 minutes.




Figure 6: Amount of clearly solubilized Isopropyl Myristate (IPM) in a surfactant base:

11.25% SLES / 3.75% CAPB / 0.5% solubilizer additive.

Application

ANTIL® Soft SC is suitable for surfactant based formulas such as body washes and shampoos.

Recommended usage concentration

The usage concentration may vary between 0.3 - 2.0 % depending on the surfactant system.

Example for clear solubility in

9% SLES / 3% CAPB / 0.7% NaCl	1.7 %
9% SLES / 3% Sodium Cocoamphoacetate	1.7 %
3.6% Disodium Lauryl Sulfosuccinate / 4.8% NaCocoamphoacetate / 4.9% CAPB (PEG-free)	1.1 %
5 % SLES / 2.5 % CAPB / 2.5 % Disodium Laureth Sulfosuccinate	1.0 %

Packaging

880 kg pallet (4 x 220 kg drums)
1050 kg container

Storage and processing hints

In general, ANTIL® Soft SC is easy to use since it is a low viscous liquid.

In standard surfactant systems like SLES/CAPB it can be added at every production step, also a final addition is possible.

Due to the lipophilic characteristic, the clear solubility is limited, depending on the surfactant system.

Possible turbidities might disappear after a few hours, at least over night.

In case not, we recommend to dissolve ANTIL® Soft SC in the concentrated primary surfactant **before** adding the water. For final adjustment of viscosity it should be possible to add at least a part of ANTIL® Soft SC at the end of processing.

It also might help to extend the stirring time.

The viscosity of ANTIL® Soft SC increases reversibly at lower temperatures.

Hazardous goods classification

Information concerning

- classification and labelling according to regulations for transport and for dangerous substances
- protective measures for storage and handling
- measures in accidents and fires
- toxicity and ecological effects

is given in our material safety data sheets.

Guide line formulations

Hair and Body Shampoo, PEG- & Sulfate free AK 175/9	
REWOTERIC® AM C (Sodium Cocoamphoacetate)	15.00 %
REWOPOL® SB F 12 P (Disodium Lauryl Sulfosuccinate)	3.80 %
ANTIL® Soft SC	0.90 %
Perfume	0.30 %
Water	64.00 %
TEGO® Betain F 50 (Cocomidopropyl Betaine)	13.00 %
Citric Acid, 30%	3.00 %
Preservative	q.s.
Preparation: Mix the ingredients in the given order at ~ 40°C. Adjust the pH value to 5.0. Viscosity (Brookfield): 3600 mPas.	

Mild Hair and Body Wash with Ecocert conform ingredients AK 224/5.8	
Lauryl Glucoside, 50%	8.00 %
ANTIL® HS 60 (Cocoamidopropyl Betaine; Glyceryl Laurate)	6.00 %
ANTIL® Soft SC	0.90 %
Water	63.55 %
TEGO® Betain F 50 (Cocamidopropyl Betaine)	20.00 %
Perfume	0.10 %
Benzyl Alcohol; Glycerin; Benzoic Acid; Sorbic Acid (Rokonsal BSB-N, ISP)	0.45 %
Citric Acid	1.00 %
Preparation: Mix the ingredients in the given order. An adequate mixing procedure and time is recommended (anchor stirrer, 15 min). Adjust the pH value to 5.0. Viscosity (Brookfield): 1600 mPas <i>Remark: under stability test (07/09)</i>	

Moisturizing Body Wash AK 131/2	
Phase A	
Sodium Laureth Sulfate (28%)	30.00 %
ANTIL® Soft SC	0.70 %
Perfume	0.30 %
Phase B	
Water	55.70 %
TEGOCEL® fluid HPM 4000 (Hydroxypropyl Methylcellulose)	1.20 %
TEGO® Betain C 60 (Cocamidopropyl Betaine)	8.10 %
TEGOSOFT® APM (PPG-3 Myristyl Ether)	1.00 %
TEGO® Pearl N 300 (Glycol Distearate; Laureth-4; Cocamidopropyl Betaine)	2.00 %
REWODERM® LI S 80 (PEG-200 Hydrogenated Glyceryl Palmate; PEG-7 Glyceryl Cocoate)	1.00 %
Preservative, Citric Acid	q.s.
Preparation: Disperse the TEGOCEL® fluid HPM 4000 in the water. Prepare phases A and B separately. Add B to A while stirring. Adjust the pH value to 5.5. Viscosity (Brookfield): 6000 mPas.	

Mild Facial Cleansing Foam AK 175/1	
Phase A	
Water	82.50 %
TEGO® Cosmo C 100 (Creatine)	0.25 %
TEGOCEL® HPM 50	0.50 %
Phase B	
TEGO® Betain 810 (Capryl/Capramidopropyl Betaine)	6.60 %
REWOPOL® SB CS 50 B (Disodium PEG-5 Laurylcitrate Sulfosuccinate; Sodium Laureth Sulfate)	8.00 %
ANTIL® Soft SC	0.70 %
Perfume	0.25 %
LACTIL® (Sodium Lactate; Sodium PCA; Glycine; Fructose; Urea; Niacinamide; Inositol; Sodium Benzoate; Lactic Acid)	1.00 %
Panthenol	0.20 %
Preservatives	q.s.
Preparation: Disperse the TEGO® Cosmo C 100 and the TEGOCEL® HPM 50 in the water. Prepare phases A and B separately. Add A to B while stirring. Add the remaining ingredients in the given order. Adjust pH-value to 5.5. Remarks: – for application with pump foamer, e.g. of Rexam/Airspray.	

Clear Moisturizing Shower Gel	
AK 175/4	
Sodium Laureth Sulfate (28%)	37.00 %
ANTIL® Soft SC	1.00 %
Perfume	0.30 %
Water	42.30 %
REWOTERIC® AM C (Sodium Cocoamphoacetate)	9.00 %
TEGO® Betain 810 (Capryl/Capramidopropyl Betaine)	7.60 %
LACTIL® (Sodium Lactate; Sodium PCA; Glycine; Fructose; Urea; Niacinamide; Inositol; Sodium Benzoate; Lactic Acid)	1.00 %
Citric Acid, 30%	1.30 %
REWODERM LI S 80 (PEG-200 Hydrogenated Glyceryl Palmate; PEG-7 Glyceryl Cocoate)	0.50 %
Preservative, Citric Acid	q.s.
Preparation: Mix the ingredients in the given order. Adjust the pH value to 5.5. Viscosity (Brookfield): 5700 mPas.	

E 03/11

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments.

The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.
(Status: April, 2008)

Evonik Industries AG Goldschmidtstraße 100 45127 Essen, Germany
P.O. BOX 45116 Essen PHONE +49 201 173-2854 FAX +49 201 173-1828
personal-care@evonik.com www.evonik.com/personal-care

